



Energy Saver Clad Wood

Sliding & French Sliding Patio Door

FeelSafe French Sliding Patio Door

Parts Pages

for:

Fastener Schedules

Fastener Schedule

Part No.	Fastener Type	Where Used
019892	GSN 18 – 1/2" Staple	Aluminum to Jamb
010608	#6 X 3/4" Phillips FL HD Screw	U-Cap to Bottom Rail
010608	#6 X 3/4" Phillips FL HD Screw	Rollers to Bottom Rail
035029	14 GA X 2 1/2" T Nail	Sash Pinning
035029	14 GA X 2 1/2" T Nail	French Sash Pinning
017806 SS	#8 X 1 1/4" Phillips FL HD	Interlock to Active Panel
011635	#6 X 5/8" Phillips Pan HD - White	Exterior Interlock to Stationary Panel
011636	#6 X 5/8" Phillips Pan HD - Bronze	Exterior Interlock to Stationary Panel
015517	#6 X 5/8" Phillips Pan HD - Sand	Exterior Interlock to Stationary Panel
032142	#6 X 5/8" Phillips Pan HD - Green	Exterior Interlock to Stationary Panel
075321	#6 X 5/8" Phillips Pan HD - Brick Red	Exterior Interlock to Stationary Panel
019928	#6 X 5/8" Phillips Pan HD - Jet Black	Exterior Interlock to Stationary Panel
014544	3/8" Staple	Panel Cardboard
017772	GSN 18 X 1" T Nail	Wood Bead to Panel
019892	GSN 18-1/2 Staple	Corner Key to Sill
015433 SS	#8 x 1" Phillips FL HD	Anti-Theft to Head
076981 SS	#8 x 5/8" Phillips FL HD	Anti-Theft to Sill
076007 SS	#8 x 1 1/2" Phillips FL HD	Anti-Theft to Panel
076007 SS	#8 x 1 1/2" Phillips FL HD	Aluminum Frame Corner
038118	#10 x 1 1/2" Phillips FL HD	Stationary Stop to Sill
011205	#8 x 1 3/4" Phillips FL HD	Sill Corner Key to Side Jamb
011637	#6 x 1 1/2" Phillips FL HD	Wood Frame Head to Side Jamb
074275	#6 x 1 1/4" Phillips FL HD	Head Inside Stop
096274	18 GA X 1 1/4" T Nail	Jamb Inside Stop
096274	18 GA X 1 1/4" T Nail	Wood Head Parting Stop
096274	18 GA X 1 1/4" T Nail	Wood Jamb Parting Stop
024588	#7 x 1 1/2" Phillips FL HD	Aluminum Head Parting Stop
024588	#7 x 1 1/2" Phillips FL HD	Aluminum Jamb Parting Stop
096274	GSN 18 X 1 1/4" T Nail	Inside SideLite Stop
039360	#8 X 2 1/2" Zinc Die. Silver PH Pan HD	Head and Jamb to Stationary Panel
017807 SS	#10 X 3" Phillips FL HD	Sill to Stationary Panel
011836	#6 X 2 3/4" Ph FI Hd Z&Y Wd Screw	Astragal Attachment
094050	18 GA 3/8" x 1/2" Staple	Aluminum Brickmould
011966	#10 X 1" Phillips FL HD	Lock Faceplate
024262	Schnee MoorHead 5731	Sash Metal Application
022016	Schnee MoorHead 5731	Sash Glazing

Note: Parts drawings not to scale.

Sliding & French Sliding Patio Door

Energy Saver Aluminum Clad Wood

Replacement Parts



DP Upgrade Fastener Schedule

Quantity	Part No.	Fastener Type	Where Used
8" – 10" Spacing	019892	GSN 18 – 1/2" Staple	Aluminum to Jamb
3	010608	#6 X 3/4" Phillips FL HD Screw	U-Cap to Bottom Rail
4	010608	#6 X 3/4" Phillips FL HD Screw	Rollers to Bottom Rail
2 Per Corner	035029	14 GA X 2 1/2" T Nail	Sash Pinning
4 Per Corner	035029	14 GA X 2 1/2" T Nail	French Sash Pinning
As Needed	011971	#8 X 1 1/4" Phillips Pan HD	Interlock to Active Panel
As Needed	011635	#6 X 5/8" Phillips Pan HD - White	Exterior Interlock to Stationary Panel
As Needed	011636	#6 X 5/8" Phillips Pan HD - Bronze	Exterior Interlock to Stationary Panel
As Needed	015517	#6 X 5/8" Phillips Pan HD - Sand	Exterior Interlock to Stationary Panel
As Needed	032142	#6 X 5/8" Phillips Pan HD - Green	Exterior Interlock to Stationary Panel
As Needed	075321	#6 X 5/8" Phillips Pan HD - Brick Red	Exterior Interlock to Stationary Panel
As Needed	019928	#6 X 5/8" Phillips Pan HD - Jet Black	Exterior Interlock to Stationary Panel
2 Per Corner	014544	3/8" Staple	Panel Cardboard
As Needed	017772	GSN 18 X 1" T Nail	Wood Bead to Panel
2 Per Side	019892	GSN 18-1/2" Staple	Corner Key to Sill
1	015433 SS	#8 x 1" Phillips FL HD	Anti-Theft to Head
1	076981 SS	#8 x 5/8" Phillips FL HD	Anti-Theft to Sill
2	076007 SS	#8 x 1 1/2" Phillips FL HD	Anti-Theft to Panel
1	076007 SS	#8 x 1 1/2" Phillips FL HD	Aluminum Frame Corner
4	038118	#10 x 1 1/2" Phillips FL HD	Stationary Stop to Sill
6	011205	#8 x 1 3/4" Phillips FL HD	Sill Corner Key to Side Jamb
6	011637	#6 x 1 1/2" Phillips FL HD	Wood Frame Head to Side Jamb
As Needed	074275	#6 x 1 1/4" Phillips FL HD	Head Inside Stop
As Needed	074275	#6 x 1 1/4" Phillips FL HD	Sill Dam
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Jamb Inside Stop
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Wood Head Parting Stop
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Wood Jamb Parting Stop
10" Spacing	024588	#7 x 1 1/2" Phillips FL HD	Aluminum Head Parting Stop
10" Spacing	024588	#7 x 1 1/2" Phillips FL HD	Aluminum Jamb Parting Stop
16" - 18" Spacing	096274	GSN 18 X 1 1/4" T Nail	Inside SideLite Stop
As Needed	039360	#8 X 2 1/2" Zinc Die. Silver PH Pan HD	Head and Jamb to Stationary Panel
3	017807 SS	#10 X 3" Phillips FL HD	Sill to Stationary Panel
As Needed	094050	18 GA 3/8" x 1/2" Staple	Aluminum Brickmould
2	011966	#10 X 1" Phillips FL HD	Lock Faceplate
6	011836	#6 X 2 3/4" Ph Fl Hd Z&Y Wd Screw	Mull Jamb Installation
As Needed	024262	Schnee MoorHead 5731	Sash Metal Application
As Needed	022016	Schnee MoorHead 5731	Sash Glazing

Note: Parts drawings not to scale.

Feelsafe Fastener Schedule

Quantity	Part No.	Fastener Type	Where Used
8" – 10" Spacing	019892	GSN 18 – 1/2" Staple	Aluminum to Jamb
3	010608	#6 X 3/4" Phillips FL HD Screw	U-Cap to Bottom Rail
4	010608	#6 X 3/4" Phillips FL HD Screw	Rollers to Bottom Rail
2 Per Corner	035029	14 GA X 2 1/2" T Nail	French Sash Pinning
As Needed	011971 SS	#8 X 1 1/4" Phillips Pan SMS	Aluminum Interlock to Active Panel
As Needed	097303 SS	#10 X 1/2" Phillips Pan SMS - SS	Exterior Interlock to STAT. Panel
As Needed	097304	#10 X 1 3/4" Phillips Pan SMS	Exterior Meeting Stile Reinforcement
2 Per Corner	014544	3/8" STAPLE	Panel Cardboard
As Needed	017772	GSN 18 X 1" T Nail	Wood Bead to Panel
2 Per Side	019892	GSN 18-1/2" Staple	Corner Key to Sill
1	015433 SS	#8 x 1" Phillips FL HD	Anti-Theft to Head
2	076981 SS	#8 x 5/8" Phillips FL HD	Anti-Theft to Sill
3	076007 SS	#8 x 1 1/2" Phillips FL HD	Anti-Theft to Panel
1	076007 SS	#8 x 1 1/2" Phillips FL HD	Aluminum Frame Corner
4	038118	#10 x 1 1/2" Phillips FL HD	Stationary Stop to Sill
6	011205	#8 x 1 3/4" Phillips FL HD	Sill Corner Key to Side Jamb
6	011637	#6 x 1 1/2" Phillips FL HD	Wood Frame Head to Side Jamb
As Needed	074275	#6 x 1 1/4" Phillips FL HD	Head Inside Stop
As Needed	074276	#6 x 1 1/4" Phillips FL HD	Sill Dam
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Jamb Inside Stop
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Wood Head Parting Stop
6" – 8" Spacing	096274	18 GA X 1 1/4" T Nail	Wood Jamb Parting Stop
6" – 8" Spacing	096274	19 GA X 1 1/4" T Nail	Wood Operator Interlock Cover
10" Spacing	024588	#7 x 1 1/2" Phillips FL HD	Aluminum Head Parting Stop
10" Spacing	024588	#7 x 1 1/2" Phillips FL HD	Aluminum Jamb Parting Stop
16" - 18" Spacing	096274	GSN 18 X 1 1/4" T Nail	Inside SideLite Stop
As Needed	039360	#8 X 2 1/2" Zinc Die. Silver PH Pan HD	Head and Jamb to Stationary Panel
3-4	017807 SS	#10 X 3" Phillips FL HD	Sill to Stationary Panel
2	011966	#10 X 1" Phillips FL HD	Lock Faceplate
As Needed	024262	Schnee Moorhead 5731	Sash Metal Application
As Needed	094042 / 094043	Tremco S-900	Sash Glazing
As Needed	094039	3M Bump-ons	Glazing Spacers
As Needed	096671	5/32" X 1 4" X 2" Neoprene	Laminated Glass Setting Blocks
As Needed	096672	5/32" X 3/4" X 3" Neoprene	Lami IG Setting Blocks

Note: Parts drawings not to scale.