



Energy Saver Clad Wood

Inswing & French Inswing Patio Door

Parts Pages

for:

Fastener Schedules

Fastener Schedule

Operating & Stationary Panels, Rectangle & Arch Units

<u>Part No.</u>	<u>Fastener Type</u>	<u>Where Used</u>
017772	<u>T-NAIL</u> GSN 18 X 1" T Nail As Required	Wood Glazing Bead to Panel
014798 STAINLESS STEEL	<u>SCREWS</u> #6 X 3/4" Phillips Pan HD - Brown	Sill Strike Plate, 2 Per Strike
085469 STAINLESS STEEL	#6 X 1-1/4" Phillips FL HD SM Type 17 As Required	- Multi-Point Hardware
090729 STAINLESS STEEL	#7 X 5/8" Phillips FL HD SM Type 17 18-8 SS As Req'd	- Stainless Steel Strike
096717 096715 096714 096716 017429	#9 X 1 1/2" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Panel Leaf Hinges
076036 096713 096712 096757 017430	#9 X 3/4" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Frame Leaf Hinge
038684 STAINLESS STEEL	#8 x 3/4" Phillips FL HD SS SM Screw	-Strikes to Head Sill (French Door) & 2Pt Shoot Bolt 2 Per Strike 2 Per Handle 4 Per Hinge
024590	#8 X 3" Phillips FL HD As Required	- Stationary Panel to Frame - Head and Jamb to Astragal
096682	#8 X 3" Phillips FL HD As Required	- French Astragal
096753 096754 096755 096756 099858	#9 X 3" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Installation Screw
024262	<u>SILICONE</u> Clear Silicone As Required	- Frame to Panel - Between Head & Side Jamb/Mulling

Transom Fastener Schedule

<u>Part No.</u>	<u>Quantity</u>	<u>Fastener Type</u>	<u>Where Used</u>
017772	4" – 6" Spacing	<u>T-NAIL</u> GA18 x 1" T-Nail	Wood Glazing Bead
010522	As Required	<u>BRAD NAIL</u> 16 GA X 1-1/2" Brad Nail	Inside Mull Casing
010659	6" – 8" Spacing	<u>CORRUGATED ILL FASTENER</u> 3/8" Corrugated Fastener	Mulling
024590	As Required	<u>SCREWS</u> #8 x 3" Phillips Flat Head SM Screw	- Astragal Tongue to Panel - Frame to Astragal
017773	As Required	#8 X 2" Phillips Flat HD PB Screw	Panel to Frame (Head and Sill)
013801	As Required	#7 X 1/2" Phillips Flat HD 100° Head Screw	Sill Panel Clip to Sill
094050	As Required	<u>STAPLES</u> 18 GA 3/8" x 1/2" Staple	Aluminum Brick Mould
076983	As Required	GS16 x 1/2" Crown Staple	Gusset Strip / Panel Shims
024262	As Required	<u>SILICONE</u> Clear Silicone	- Frame to Panel - Between Head & Side Jamb/Mulling

ADA Sill Fastener Schedule

<u>Part No.</u>	<u>Fastener Type</u>	<u>Where Used</u>
017772	<u>T-NAIL</u> GSN 18 X 1" T Nail As Required	Wood Glazing Bead to Panel
013801 STAINLESS STEEL	<u>SCREWS</u> #7 X 1/2" Phillips Pan HD As Required	Sill Strike Plate 2 Per Strike
085469 STAINLESS STEEL	#6 X 1-1/4" Phillips FL HD SM Type 17 As Required	- Multi-Point Hardware
090729 STAINLESS STEEL	#7 X 5/8" Phillips FL HD SM Type 17 18-8 SS As Req'd	- Stainless Steel Strike
096717 096715 096714 096716 017429	#9 X 1 1/2" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Panel Leaf Hinges
076036 096713 096712 096757 017430	#9 X 3/4" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Frame Leaf Hinge
038684 STAINLESS STEEL	#8 x 3/4" Phillips FL HD SS SM Screw	-Strikes to Head Sill (French Door) & 2Pt Shoot Bolt 2 Per Strike 2 Per Handle 4 Per Hinge
024590	#8 X 3" Phillips FL HD As Required	- Stationary Panel to Frame - Head and Jambs to Astragal
096682	#8 X 3" Phillips FL HD As Required	- French Astragal
096753 096754 096755 096756 099858	#9 X 3" PH FL Head Screw As Required Bright Brass Antique Brass White Brushed Chrome (Polished Chrome) Champagne	- Installation Screws
024262	<u>SILICONE</u> Clear Silicone As Required	- Frame to Panel - Between Head & Side Jamb/Mulling
076986	Clear Silicone As Required	- Cap Beading of Jamb At Sill